

2) DRAIN VALVE AND CONDENSATE DRAIN HOSE SHOULD BE ARRANGED TO PERMIT THE FLUIDS TO DRAIN FREELY, BY GRAVITY, TO A CONVENIENT FLOOR DRAIN. RELIEF VALVES SHOULD BE PIPED VERTICALLY TO A HEIGHT 18" ABOVE FLOOR.

3) ALL PIPING AND ELECTRIC CONNECTIONS (SERVICE SWITCHES, CONDUIT BOXES) SHOULD BE A MINIMUM OF 6" AWAY FROM SIDE

4) GAS REGULATOR IS REQUIRED WHEN SUPPLY PRESSURE IS GREATER THAN 13" W.C.

5) THIS IS A TYPICAL INSTALLATION DRAWING. LOCAL CODES AND AUTHORITIES SHOULD BE CONSULTED.



REV. DATE

INTERNATIONAL, INC.

AMR MODELS 399 & 500 SKID STYLE GAS FIRED SINGLE UNIT INSTALLATION

DWN. BY J.R. DATE 050415 SCALE NTS

SD-A-1069