



NOTES:

- 1) FOR ACTUAL SIZES AND LOCATIONS OF PIPING AND OTHER CONNECTIONS TO THE BOILER, SEE APPROPRIATE DIMENSIONAL DRAWING.
- 2) DRAIN VALVE AND CONDENSATE DRAIN HOSE SHOULD BE ARRANGED TO PERMIT THE FLUIDS TO DRAIN FREELY, BY GRAVITY, TO A CONVENIENT FLOOR DRAIN. RELIEF VALVES SHOULD BE PIPED VERTICALLY TO A HEIGHT 18" ABOVE FLOOR.
- 3) ALL PIPING AND ELECTRIC CONNECTIONS (SERVICE SWITCHES, CONDUIT BOXES) SHOULD BE A MINIMUM OF 6" AWAY FROM SIDE PANELS.
- 4) GAS REGULATOR IS REQUIRED WHEN SUPPLY PRESSURE IS GREATER THAN 13" W.C.
- 5) THIS IS A TYPICAL INSTALLATION DRAWING. LOCAL CODES AND AUTHORITIES SHOULD BE CONSULTED.

INTERNATIONAL, INC. <small>Blauvelt, NY 10913</small>	
AMR MODELS 750&1000 GAS FIRED SINGLE UNIT INSTALLATION	
DWN. BY <u>J.R.</u> DATE <u>050115</u> SCALE <u>NTS</u> APPD. _____ DATE _____	SD-A-1067 REV A