



NOTES:

- 1) MODULEX PIPING GUIDE GF-115-P FOR INSTALLATION DETAILS.
- 2) WHEN USING THE AERCO CONDENSATE NEUTRALIZER TANK, FOR PROPER CONDENSATE DRAINAGE, THE NEUTRALIZER TANK MUST BE INSTALLED IN A PIT OR THE BOILER AND THE AERCO CONDENSATE TRAP MUST BE ELEVATED HIGHER THAN 4" ABOVE THE FLOOR. SEE CONDENSATE TANK INSTRUCTIONS TID-0074 FOR DETAILS.

AERCO INTERNATIONAL, INC.
Blauvelt, NY 10913

MODULEX GAS FIRED BOILER
CONDENSATE DRAIN INSTALLATION

DWN. BY CZ DATE 091206
SCALE NTS
APPD. _____ DATE _____

SD-A-694

REV.
D