

NOTES:

- 1. REFER TO BOILER INSTALLATION DRAWINGS FOR RECOMMENDED FIELD INSTALLATION.
- 2. REFER TO SMARTPLATE APPLICATIONS GUIDE, SP-1010, FOR BUFFER TANK SIZING.
- 3. REFER TO SMARTPLATE INSTALLATION DRAWINGS FOR RECOMMENDED DOMESTIC PIPING INSTALLATION.
 - SD-A-772
 - SD-A-773
 - SD-A-774
 - SD-A-775
 - SD-A-776
 - SD-A-777
- 4. BOILER PUMP MUST BE SIZED TO PROVIDE THE APPROPRIATE FLOW AT THE DESIGN ΔT OF THE BOILER PLANT. BOILER PUMP MUST MAINTAIN MODULEX BOILER(S) REQUIRED MINIMUM FLOW:
 - MLX 321 12 GPM MINIMUM FLOW
 - MLX 481 18 GPM MINIMUM FLOW
 - MLX 642 24 GPM MINIMUM FLOW
 - MLX 802 30 GPM MINIMUM FLOW
 - MLX 963 35 GPM MINIMUM FLOW
 - MLX 1123- 41 GPM MINIMUM FLOW
- MLX 1123- 41 GFM MINIMUM FLOW
- 5. INSTALL THE BMS HEADER SENSOR IN THE BUFFER TANK SYSTEM SUPPLY PIPING.
- 6. ALL (*) ITEMS ARE INCLUDED SEPARATELY IN SHIPMENT FROM FACTORY.
- 7. THE MANIFOLD FOR THESE COMPONENTS IS ALSO INCLUDED SEPARATELY IN SHIPMENT FROM FACTORY.

INTERNATIONAL, INC.
Blauvelt, NY 10913

SMARTPLATE & MODULEX
MULTIPLE UNITS WITH BOILER
SIDE BUFFER TANK DEDICATED
TO DOMESTIC WATER HEATING

DWN. BY	CZ	DATE	041910
SCALE _	NTS		
APPD.		DATE	

SD-A-809

REV C