


USE 90° ELBOWS
 INTO AND OUT OF
 THE STEAM TRAP



A PARALLEL PIPE STEAM TRAP CAN BE ORIENTED USING ONE OF THE ABOVE DIAGRAMS.

NOTE: THE ABOVE DIAGRAMS DEPICT ONLY THE ORIENTATION OF THE STEAM TRAP. SEE WATER HEATER PIPING DIAGRAM FOR COMPLETE INSTALLATION DETAILS.

AERCO INTERNATIONAL, INC.
 NORTHVALE, NJ 07647

PARALLEL PIPE STEAM TRAP
 INSTALLATION ORIENTATION
 GUIDELINE

DRWN BY: CZ
 DATE: 10/04/10

AP-A-887

REV.
 A