


NOTES:

- 1) FOR ACTUAL SIZES AND LOCATIONS OF PIPING AND OTHER CONNECTIONS TO THE BOILER, SEE APPROPRIATE DIMENSIONAL DRAWING.
- 2) SHELL DRAIN VALVE AND CONDENSATE DRAIN TRAP SHOULD BE ARRANGED TO PERMIT THE FLUIDS TO DRAIN FREELY, BY GRAVITY, TO A CONVENIENT FLOOR DRAIN. RELIEF VALVE SHOULD BE PIPED VERTICALLY TO A HEIGHT 18" ABOVE FLOOR.
- 3) ALL (*) ITEMS ARE INCLUDED SEPARATELY IN SHIPMENT FROM FACTORY.
- 4) THE MANIFOLD FOR THESE COMPONENTS IS ALSO INCLUDED SEPARATELY IN SHIPMENT FROM FACTORY.
- 5) LOCATE WATER INLET AND OUTLET FITTINGS (i.e. ELBOWS, ETC.) A MINIMUM OF 6" FROM BOILER FITTINGS TO PREVENT INTERFERENCE WITH REMOVAL OF BOILER PANELS AND COVERS. ALL PIPING AND ELECTRIC CONNECTIONS (SERVICE SWITCHES, CONDUIT BOXES) SHOULD LIKEWISE BE 6" AWAY FROM SIDE PANELS.
- 6) MANDATORY PRIMARY PUMP - SEE AERCO MODULEX PRIMARY LOOP DESIGN DATA - ENGR. MANUAL C400.2 OR O&M MANUAL GF-139.
- 7) MANDATORY BOILER STRAINER (20 MESH OR FINER).
- 8) GAS REGULATOR IS MANDATORY AND IS REQUIRED WHEN SUPPLY PRESSURE IS GREATER THAN 14" W.C.
- 9) THIS IS A TYPICAL INSTALLATION DRAWING. LOCAL CODES AND AUTHORITIES SHOULD BE CONSULTED.
- 10) WHEN USING THE AERCO CONDENSATE NEUTRALIZER TANK, FOR PROPER CONDENSATE DRAINAGE, THE NEUTRALIZER TANK MUST BE INSTALLED IN A PIT OR THE BOILER AND THE AERCO CONDENSATE TRAP MUST BE ELEVATED HIGHER THAN 4" ABOVE THE FLOOR. SEE CONDENSATE TANK INSTRUCTIONS TID-0074 FOR DETAILS.

		100 ORITANI DRIVE BLAUVELT, NY 10913 aerco.com	
MLX EXT 1500-3000/1530-3060 MBH GAS FIRED BOILER MULTIPLE UNIT INSTALLATION W/ HYDRAULIC SEPARATOR			
DWN. BY <u>K.S.</u> DATE <u>080613</u>		SD-A-987	
SCALE <u>NTS</u>			
REV. DATE <u>K.S. 020717</u>			
		REV B	