




Zoning

**Q313**


11/10

Replaces: 04/09

## 1. Location



## 2. Install Junction Box




## 3. Size Transformer

Zone	1	2	3	4	
Thermostat Load					
Zone Valve Load					<b>Control Load (VA)</b>
Total Zone Load	+ _____	+ _____	+ _____	+ _____	<b>3</b> →

Transformer must exceed:  
 \_\_\_\_\_ VA

## 4. Line Voltage Wiring



## 5. Install Enclosure

