

NOTES:

1) FOR ACTUAL SIZES AND LOCATIONS OF PIPING AND OTHER CONNECTIONS TO THE BOILER, SEE APPROPRIATE DIMENSIONAL DRAWING.

2) DRAIN VALVE AND CONDENSATE DRAIN HOSE SHOULD BE ARRANGED TO PERMIT THE FLUIDS TO DRAIN FREELY, BY GRAVITY,

TO A CONVENIENT FLOOR DRAIN. RELIEF VALVES SHOULD BE PIPED VERTICALLY TO A HEIGHT 18" ABOVE FLOOR.

3) ALL PIPING AND ELECTRIC CONNECTIONS (SERVICE SWITCHES, CONDUIT BOXES) SHOULD BE A MINIMUM OF 6" AWAY FROM SIDE PANELS.

4) GAS REGULATOR IS REQUIRED WHEN SUPPLY PRESSURE IS GREATER THAN 13" W.C.

5) THIS IS A TYPICAL INSTALLATION DRAWING. LOCAL CODES AND AUTHORITIES SHOULD BE CONSULTED.



INTERNATIONAL, INC. Blauvelt, NY 10913

AMR MODELS 750&1000 GAS FIRED MULTIPLE UNIT INSTALLATION

DWN. BY J.R. DATE 050115 SCALE NTS

SD-A-1068