

## NOTES:

- 1) FOR ACTUAL SIZES AND LOCATIONS OF PIPING AND OTHER CONNECTIONS TO THE BOILER, SEE APPROPRIATE DIMENSIONAL DRAWING.
- 2) DRAIN VALVE AND CONDENSATE DRAIN HOSE SHOULD BE ARRANGED TO PERMIT THE FLUIDS TO DRAIN FREELY, BY GRAVITY, TO A CONVENIENT FLOOR DRAIN. RELIEF VALVES SHOULD BE PIPED VERTICALLY TO A HEIGHT 18" ABOVE FLOOR.
- 3) ALL PIPING AND ELECTRIC CONNECTIONS (SERVICE SWITCHES, CONDUIT BOXES) SHOULD BE A MINIMUM OF 6" AWAY FROM SIDE
- 4) GAS REGULATOR IS REQUIRED WHEN SUPPLY PRESSURE IS GREATER THAN 13" W.C.
- 5) THIS IS A TYPICAL INSTALLATION DRAWING. LOCAL CODES AND AUTHORITIES SHOULD BE CONSULTED.



INTERNATIONAL, INC. Blauvelt, NY 10913

AMR MODELS 399 & 500 SKID STYLE GAS FIRED MULTIPLE UNIT INSTALLATION

| DWN. | BY | J.R. | DATE | 050415 |
|------|----|------|------|--------|
|      |    | NTS  |      |        |

REV. DATE

SD-A-1070 B